

# **Quick Bacteria Genomic DNA Extraction Kit**

Component	D1011	D1012
	50 preps	100 preps
Solution DS	15 ml	30 ml
Solution MS	20 ml	40 ml
Proteinase K (20 mg/ml)	1 ml	2 ml
Wash Buffer PS	18 ml	36 ml
Wash Buffer PE	15 ml	30 ml
Elution Buffer TE (10 mM Tris-HCl, 1 mM EDTA, pH 8.5)	5 ml	10 ml
Spin Columns	50 each	100 each

# Catalog No.: D1011 (50 preps) D1012 (100 preps)

#### Description

**Kit Contents** 

The Genomic DNA extraction system uses the silica-based membrane technology for simple and fast isolation of genomic DNA (gDNA) without phenol/chloroform. Homogenization is not necessary since tissues are directly lysed by Proteinase K. The buffer system is optimized to allow selective binding of DNA to the silica-based membrane. The simple centrifugation procedure can completely removes impurities such as proteins, divalent cations, and secondary metabolites. Pure DNA is then eluted in water or low-salt buffer, ready to use.

Genomic DNA Purification Kit is suitable for high quality genomic DNA purification of tissues from Gram Positive and Gram Negative Bacteria.

# **Downstream Applications**

Purified DNA is free of impurities and enzyme inhibitors, and have an  $A_{260/280}$  = 1.7-1.9, is suitable for applications such as:

- Genotyping
- PCR/qPCR
- Restriction enzyme digestion
- Sequencing
- Southern blotting

# Features

- Fast procedure takes only 30 min
- **High efficiency** 3-20  $\mu$ g of genomic DNA from 1.5 2 ml bacteria culure
- Safe no phenol/cholroform extraction step
- **High purity** purified DNA without enzyme inhibitors, RNA or proteins, ready for downstream applications

BKL ZONE. Calle Finlandia, parcela 108, nave 5. Polígono Industrial Tecnocórdoba. 14014 Córdoba, España.

Web: b-kl.eu e-mail: b-kl@b-kl.eu



#### Storage

Store Proteinase K at -20°C, other reagents at room temperature for up to 1 year. Any precipitate in the Solution DS and Solution MS can be dissolved by incubating at 37°C before use.

#### **Important Notes**

• Prior to the initial use of the kit, dilute the Wash Buffer PS, Wash Buffer PE with isopropyl alcohol or ethanol (96-100%):

Solution	D1011 (50 preps)	D1012 (100 preps)
Wash Buffer PS	18 ml	36 ml
Isopropyl Alcohol	12 ml	24 ml
Total Volume	30 ml	60 ml
Solution	D1011 (50 preps)	D1012 (100 preps)
Solution Wash Buffer PE	<b>D1011 (50 preps)</b> 15 ml	D1012 (100 preps) 30 ml

Mix well, mark the labels on the bottle that isopropyl alcohol or ethanol is added.

introduced sterile solutions Ensure that no DNases are into the of kit. the • Make sure there is no precipitates in Solution DS and Solution MS. If any precipitate is visible, warming the solutions at  $37^{\circ}$ C for 3-5 min to dissolve the precipitate, and cooling to  $25^{\circ}$ C before use. • Wear disposable gloves when handling the Solution MS as it contains guanidine hydrochloride.

• All purification steps should be carried out at room temperature. • All centrifugations should be carried out by a table-top microcentrifuge at>1,2000 g (10,000-14,000 rpm, depending on the rotor type).

# Protocol

- 1. Add 0.5 2 ml of overnight bacteria culture ( $\sim 2 \times 10^9$  cells) to a 1.5 ml microcentrifuge tube. Centrifuge at 12,000 rpm for 1 min to pellet the cells. Remove the supernatant.
- Add 200 μl Solution DS. Mix immediately and thoroughly by brief vortexing or inverting. Note • For Gram Positive Bacteria, add 108 μl Solution DS and 72 μl lysyme (50 mg/ml, catalog No.: N9021), mix well by brief vortexing or inverting. Incubate at 37 °C for 30 min.

**Optional** • If RNA-free genomic DNA is required, add  $4 \mu l$  RNase A (100 mg/ml) and incubate for 5 min at room temperature. RNase A can be purchased separately.

- 3. Add 20 μl **Proteinase K**, Mix thoroughly by brief vortexing or inverting. Incubate at 55°C until yield a homogeneous solution (~30 min).
- 4. Add 220 μl **Solution MS**, Mix thoroughly by brief vortexing or inverting. Incubate at 65°C for 10 min (inverting several times to yield a homogeneous solution.

BKL ZONE. Calle Finlandia, parcela 108, nave 5. Polígono Industrial Tecnocórdoba. 14014 Córdoba, España.

Web: b-kl.eu e-mail: b-kl@b-kl.eu



- 5. Add 220 µl **ethanol (96–100%)** to the lysate, and mix thoroughly by brief vortexing or inverting.
- Pipet the mixture from step 5 into the spin column placed in a 2 ml collection tube (provided). Centrifuge at 12,000 rpm for 1 min. Discard flow-through.
  Note Genomic DNA is adsorbed on the silica membrane of the column in this step.
- Add 500 μl Wash Buffer PS, and centrifuge for 1 min at 12,000 rpm. Discard flow-through. Note • Wash Buffer PS must be diluted with isopropyl alcohol previously.
- Add 500 μl Wash Buffer PE, and centrifuge for 1 min at 12,000 rpm. Discard flow-through. Note • Wash Buffer PE must be diluted with ethanol (96-100%) previously.
- 9. Repeat step 8.
- Centrifuge for 3 min at 12,000 rpm to dry the column membrane. Discard flow-through and collection tube.
  Note Since residual ethanol may interfere with subsequent reactions, it is important to dry the membrane of the spin column. This centrifugation step ensures that no residual ethanol will be carried during the following elution step. If carryover of ethanol occurs, empty the collection tube, then reuse it after centrifuging for 1 min at 12,000 rpm.
- Place the spin column in a clean 1.5 ml microcentrifuge tube (not provided), and pipet 30-100 μl Elution Buffer TE directly onto the membrane. Incubate at room temperature for 2 min. Note • Elution buffer TE can be replaced by deionized water. But the pH should be 8.0-8.5.

• Prewarm Elution Buffer TE to 65  $^{\circ}C$  can increase the yield of genomic DNA.

12. Centrifuge for 2 min at 12,000 rpm. The tube contains the purified DNA. Store the DNA at -20°C.